

# Setup Sheet Report

# GENERIC HAAS 3 - AXIS VMC

## **GENERAL INFORMATION**


PROJECT NAME: CUSTOMER NAME: PROGRAMMER:

DRAWING: REVISION:

DATE: Wednesday, March 8, 2023


TIME: 11:41 AM

# C:\USERS\WESTONSHAKESPEAR\DOWNLOADS\WSHAKESPEAR\_MILL 8B.EMCAM





1.5745 in Inch



STOCK: YES SHAPE: Box

SIZE: 7.75, 4.25, 0.575

RADIUS: NA

LENGTH:

AXIS: NA

FILE:

IDN: NA

# C:\USERS\WESTONSHAKESPEAR\DOCUMENTS\MY

CYCLE TIME: 0 HOURS, 13 MINUTES, 35 SECONDS

#### **OPERATION LIST**

OPERATION INFO 1 - Facing

CYCLE TIME: 0 HOURS, 2 MINUTES, 5 SECONDS

COMMENT:

PROGRAM NUMBER: 0

SPINDLE SPEED: 4966 RPM FEEDRATE: 55.0 inch/min

CLEARANCE PLANE: 2.0

RETRACT PLANE: 0.125

FEED PLANE: 0.05

DEPTH: 0.0

STOCK TO LEAVE: 0.0

COMP TO TIP: YES

WORK OFFSET: 0


TOOL INFO 1/2 FLAT ENDMILL

TYPE: Flat endmill

NUMBER: 1
DIAMETER: 0.5
CORNER RADIUS: 0.0
LENGTH OFFSET: 1
DIAMETER OFFSET: 1
MATERIAL: HSS
NUMBER OF FLUTES: 4

FPT: 0.0015 SFM: 139.9215

MFG CODE: ASSEMBLY:



#### OPERATION INFO 2 - 2D High Speed (2D Dynamic Rest Mill)

CYCLE TIME: 0 HOURS, 6 MINUTES, 3 SECONDS

COMMENT:

PROGRAM NUMBER: 0

SPINDLE SPEED: 4966 RPM FEEDRATE: 49.0 inch/min

CLEARANCE PLANE: 0.0


RETRACT PLANE: 0.125

FEED PLANE: 0.05

DEPTH: 0.0

STOCK TO LEAVE: 0.0 0.01 COMP TO TIP: YES

WORK OFFSET: 0




# TOOL INFO 1/2 FLAT ENDMILL

TYPE: Flat endmill

NUMBER: 1
DIAMETER: 0.5
CORNER RADIUS: 0.0
LENGTH OFFSET: 1
DIAMETER OFFSET: 1
MATERIAL: HSS
NUMBER OF FLUTES: 4

FPT: 0.0015 SFM: 139.9215

MFG CODE: ASSEMBLY:



#### OPERATION INFO 3 - 2D High Speed (2D Dynamic Rest Mill)

CYCLE TIME: 0 HOURS, 2 MINUTES, 17 SECONDS

COMMENT:

PROGRAM NUMBER: 0

SPINDLE SPEED: 4966 RPM FEEDRATE: 49.0 inch/min

CLEARANCE PLANE: 0.0


RETRACT PLANE: 0.125

FEED PLANE: 0.05

DEPTH: 0.0

STOCK TO LEAVE: 0.0 0.01 COMP TO TIP: YES

WORK OFFSET: 0




#### TOOL INFO 1/2 FLAT ENDMILL

TYPE: Flat endmill

NUMBER: 1
DIAMETER: 0.5
CORNER RADIUS: 0.0
LENGTH OFFSET: 1
DIAMETER OFFSET: 1
MATERIAL: HSS
NUMBER OF FLUTES: 4

FPT: 0.0015 SFM: 139.9215

MFG CODE: ASSEMBLY:



#### OPERATION INFO 4 - 2D High Speed (2D Dynamic Rest Mill)

CYCLE TIME: 0 HOURS, 0 MINUTES, 44 SECONDS

COMMENT:

PROGRAM NUMBER: 0

SPINDLE SPEED: 4966 RPM FEEDRATE: 49.0 inch/min

CLEARANCE PLANE: 0.0

RETRACT PLANE: 0.125

FEED PLANE: 0.05

DEPTH: 0.0

STOCK TO LEAVE: 0.0 0.01
COMP TO TIP: YES
WORK OFFSET: 0



TYPE: Flat endmill NUMBER: 1
DIAMETER: 0.5
CORNER RADIUS: 0.0

CORNER RADIUS: 0.0

LENGTH OFFSET: 1


DIAMETER OFFSET: 1


MATERIAL: HSS

NUMBER OF FLUTES: 4

FPT: 0.0015 SFM: 139.9215

MFG CODE: ASSEMBLY:





#### OPERATION INFO

## 5 - Contour (2D)

CYCLE TIME:

0 HOURS, 0 MINUTES, 26 SECONDS

COMMENT:

PROGRAM NUMBER: 0

SPINDLE SPEED: 4966 RPM FEEDRATE: 55.0 inch/min

CLEARANCE PLANE: 2.0

RETRACT PLANE: 0.25


FEED PLANE: 0.2

DEPTH: 0.0

STOCK TO LEAVE: 0.0

COMP TO TIP: YES

WORK OFFSET: 0



#### TOOL INFO


#### 1/2 FLAT ENDMILL

TYPE: Flat endmill

NUMBER: 1
DIAMETER: 0.5
CORNER RADIUS: 0.0
LENGTH OFFSET: 1
DIAMETER OFFSET: 1
MATERIAL: HSS
NUMBER OF FLUTES: 4

FPT: 0.0015 SFM: 139.9215

MFG CODE: ASSEMBLY:



#### OPERATION INFO

CYCLE TIME:

0 HOURS, 0 MINUTES, 18 SECONDS

6 - Contour (2D)

COMMENT:

PROGRAM NUMBER: 0

SPINDLE SPEED: 4966 RPM FEEDRATE: 55.0 inch/min

CLEARANCE PLANE: 2.0

RETRACT PLANE: 0.25


FEED PLANE: 0.2

DEPTH: 0.0

STOCK TO LEAVE: 0.0

COMP TO TIP: YES

WORK OFFSET: 0




#### TOOL INFO 1/2 FLAT ENDMILL

TYPE: Flat endmill

NUMBER: 1
DIAMETER: 0.5
CORNER RADIUS: 0.0
LENGTH OFFSET: 1
DIAMETER OFFSET: 1
MATERIAL: HSS
NUMBER OF FLUTES: 4

FPT: 0.0015 SFM: 139.9215

MFG CODE: ASSEMBLY:



#### OPERATION INFO

CYCLE TIME:

0 HOURS, 0 MINUTES, 25 SECONDS


7 - Contour (2D)

COMMENT:

PROGRAM NUMBER: 0

SPINDLE SPEED: 4966 RPM FEEDRATE: 55.0 inch/min

CLEARANCE PLANE: 2.0
RETRACT PLANE: 0.25
FEED PLANE: 0.2
DEPTH: 0.0
STOCK TO LEAVE: 0.0
COMP TO TIP: YES
WORK OFFSET: 0




#### TOOL INFO 1/2 FLAT ENDMILL

TYPE: Flat endmill NUMBER: 1
DIAMETER: 0.5
CORNER RADIUS: 0.0

CORNER RADIUS: 0.0
LENGTH OFFSET: 1
DIAMETER OFFSET: 1
MATERIAL: HSS
NUMBER OF FLUTES: 4

FPT: 0.0015 SFM: 139.9215

MFG CODE: ASSEMBLY:



#### OPERATION INFO 8 - Contour (2D chamfer)

CYCLE TIME: 0 H

0 HOURS, 0 MINUTES, 40 SECONDS

COMMENT:

PROGRAM NUMBER: 0

SPINDLE SPEED: 4966 RPM FEEDRATE: 55.0 inch/min

CLEARANCE PLANE: 2.0

RETRACT PLANE: 0.125


FEED PLANE: 0.05

DEPTH: 0.0

STOCK TO LEAVE: 0.0

COMP TO TIP: YES

WORK OFFSET: 0




#### TOOL INFO 1/2 SPOTDRILL

TYPE: Spot drill 2 NUMBER: DIAMETER: 0.5 **CORNER RADIUS:** 0.0 LENGTH OFFSET: 2 DIAMETER OFFSET: 2 MATERIAL: HSS NUMBER OF FLUTES: 2

FPT: 0.001 SFM: 69.8953

MFG CODE: ASSEMBLY:



#### OPERATION INFO 9 - Contour (2D chamfer)

CYCLE TIME: 0 HOURS, 0 MINUTES, 4 SECONDS

COMMENT:

PROGRAM NUMBER: 0

SPINDLE SPEED: 4966 RPM FEEDRATE: 55.0 inch/min

CLEARANCE PLANE: 2.0

RETRACT PLANE: 0.125


FEED PLANE: 0.05

DEPTH: 0.0

STOCK TO LEAVE: 0.0

COMP TO TIP: YES

WORK OFFSET: 0




#### TOOL INFO 1/2 SPOTDRILL

TYPE: Spot drill
NUMBER: 2
DIAMETER: 0.5
CORNER RADIUS: 0.0
LENGTH OFFSET: 2
DIAMETER OFFSET: 2
MATERIAL: HSS

NUMBER OF FLUTES: 2 FPT: 0.001 SFM: 69.8953

MFG CODE:

ASSEMBLY:



#### OPERATION INFO 10 - Drill/Counterbore

CYCLE TIME: 0 HOURS, 0 MINUTES, 2 SECONDS

COMMENT:

PROGRAM NUMBER: 0

SPINDLE SPEED: 4966 RPM FEEDRATE: 35.0 inch/min

CLEARANCE PLANE: 0.25
RETRACT PLANE: 0.125
FEED PLANE: 0.125
DEPTH: -0.1455
STOCK TO LEAVE: 0.0
COMP TO TIP: NO

WORK OFFSET: 0




TYPE: Spot drill
NUMBER: 2
DIAMETER: 0.5
CORNER RADIUS: 0.0
LENGTH OFFSET: 2
DIAMETER OFFSET: 2
MATERIAL: HSS

NUMBER OF FLUTES: 2

FPT: 0.001 SFM: 69.8953

MFG CODE: ASSEMBLY:



#### OPERATION INFO 11 - Drill/Counterbore

CYCLE TIME:


0 HOURS, 0 MINUTES, 0 SECONDS

COMMENT:

PROGRAM NUMBER: 0

SPINDLE SPEED: 4966 RPM FEEDRATE: 35.0 inch/min

CLEARANCE PLANE: 0.25
RETRACT PLANE: 0.125
FEED PLANE: 0.125
DEPTH: -0.1455
STOCK TO LEAVE: 0.0
COMP TO TIP: NO
WORK OFFSET: 0




#### TOOL INFO 1/2 SPOTDRILL

TYPE: Spot drill
NUMBER: 2
DIAMETER: 0.5
CORNER RADIUS: 0.0
LENGTH OFFSET: 2
DIAMETER OFFSET: 2
MATERIAL: HSS

NUMBER OF FLUTES: 2

FPT: 0.001 SFM: 69.8953

MFG CODE: ASSEMBLY:



#### OPERATION INFO 12 - Peck Drill

CYCLE TIME:

0 HOURS, 0 MINUTES, 16 SECONDS


COMMENT:

PROGRAM NUMBER: 0

SPINDLE SPEED: 4966 RPM FEEDRATE: 35.0 inch/min

CLEARANCE PLANE: 0.25
RETRACT PLANE: 0.125
FEED PLANE: 0.125
DEPTH: -0.1405
STOCK TO LEAVE: 0.0
COMP TO TIP: NO

WORK OFFSET: 0



# TOOL INFO NO. 7 DRILL

TYPE: Drill

NUMBER: 3

DIAMETER: 0.201

CORNER RADIUS: 0.0

LENGTH OFFSET: 3


DIAMETER OFFSET: 3

MATERIAL: HSS

NUMBER OF FLUTES: 2

FPT: 0.0048 SFM: 399.9479

MFG CODE: ASSEMBLY:



#### OPERATION INFO 13 - Peck Drill

CYCLE TIME:

0 HOURS, 0 MINUTES, 1 SECONDS

COMMENT:

PROGRAM NUMBER: 0

SPINDLE SPEED: 4966 RPM FEEDRATE: 35.0 inch/min

CLEARANCE PLANE: 0.25

RETRACT PLANE: 0.125

FEED PLANE: 0.125

DEPTH: -0.1405

STOCK TO LEAVE: 0.0

COMP TO TIP: NO

WORK OFFSET: 0



#### TOOL INFO NO. 7 DRILL

TYPE: Drill

NUMBER: 3

DIAMETER: 0.201

CORNER RADIUS: 0.0

LENGTH OFFSET: 3


DIAMETER OFFSET: 3

MATERIAL: HSS

NUMBER OF FLUTES: 2

FPT: 0.0048 SFM: 399.9479

MFG CODE: ASSEMBLY:



#### OPERATION INFO 14 - Contour (2D)

CYCLE TIME:

0 HOURS, 0 MINUTES, 6 SECONDS

COMMENT:

PROGRAM NUMBER: 0

SPINDLE SPEED: 4966 RPM FEEDRATE: 29.0 inch/min

CLEARANCE PLANE: 2.0

RETRACT PLANE: 0.125


FEED PLANE: 0.05

DEPTH: -0.008

STOCK TO LEAVE: 0.0

COMP TO TIP: YES

WORK OFFSET: 0




#### TOOL INFO 1/8 SPOTDRILL

TYPE: Spot drill 4 NUMBER: DIAMETER: 0.125 **CORNER RADIUS:** 0.0 LENGTH OFFSET: 4 DIAMETER OFFSET: 4 MATERIAL: HSS NUMBER OF FLUTES: 2

FPT: 0.0002 SFM: 69.9935

MFG CODE: ASSEMBLY:



TOOL LIST Sorted: NO

#### TOOL INFO 1/2 FLAT ENDMILL

TYPE: Flat endmill

NUMBER: 1

DIAMETER: 0.5

CORNER RADIUS: 0.0

LENGTH OFFSET: 1

DIAMETER OFFSET: 1


MATERIAL: HSS

NUMBER OF FLUTES: 4

FPT: 0.0015 SFM: 139.9215

MFG CODE: ASSEMBLY:

HOLDER: Default Holder TIME: 00:12:21



USED BY OPERATION: #1 1 - Facing

USED BY OPERATION: #2 2 - 2D High Speed (2D Dynamic Rest Mill)
USED BY OPERATION: #3 3 - 2D High Speed (2D Dynamic Rest Mill)
USED BY OPERATION: #4 4 - 2D High Speed (2D Dynamic Rest Mill)

USED BY OPERATION: #5 5 - Contour (2D)
USED BY OPERATION: #6 6 - Contour (2D)
USED BY OPERATION: #7 7 - Contour (2D)

#### TOOL INFO 1/2 SPOTDRILL

TYPE: Spot drill
NUMBER: 2
DIAMETER: 0.5
CORNER RADIUS: 0.0
LENGTH OFFSET: 2
DIAMETER OFFSET: 2
MATERIAL: HSS

FPT: 0.001 SFM: 69.8953

MFG CODE: ASSEMBLY:

NUMBER OF FLUTES:

HOLDER: Default Holder
TIME: 00:00:48

1.000 4.000 3.000

USED BY OPERATION: #8 8 - Contour (2D chamfer)
USED BY OPERATION: #9 9 - Contour (2D chamfer)
USED BY OPERATION: #10 10 - Drill/Counterbore
USED BY OPERATION: #11 11 - Drill/Counterbore

2

#### TOOL INFO NO. 7 DRILL

TYPE: Drill
NUMBER: 3
DIAMETER: 0.201
CORNER RADIUS: 0.0
LENGTH OFFSET: 3
DIAMETER OFFSET: 3
MATERIAL: HSS
NUMBER OF FLUTES: 2

FPT: 0.0048 SFM: 399.9479

MFG CODE: ASSEMBLY:

HOLDER: Default Holder TIME: 00:00:18

USED BY OPERATION: #12 12 - Peck Drill
USED BY OPERATION: #13 13 - Peck Drill

TOOL INFO 1/8 SPOTDRILL


TYPE: Spot drill NUMBER: 4 DIAMETER: 0.125 **CORNER RADIUS:** 0.0 LENGTH OFFSET: 4 DIAMETER OFFSET: 4 MATERIAL: HSS NUMBER OF FLUTES: 2


FPT: 0.0002 SFM: 69.9935

MFG CODE: ASSEMBLY:

HOLDER: Default Holder TIME: 00:00:06

USED BY OPERATION: #14 14 - Contour (2D)





# WORK OFFSETS

# OFFSET INFO

NUMBER: 0 PLAN	E: Top	ORIGIN: 0.0, 0.0, 0.0
USED BY OPERATION:	# 1	1 - Facing
USED BY OPERATION:	#2	2 - 2D High Speed (2D Dynamic Rest Mill)
USED BY OPERATION:	#3	3 - 2D High Speed (2D Dynamic Rest Mill)
USED BY OPERATION:	#4	4 - 2D High Speed (2D Dynamic Rest Mill)
USED BY OPERATION:	# 5	5 - Contour (2D)
USED BY OPERATION:	#6	6 - Contour (2D)
USED BY OPERATION:	#7	7 - Contour (2D)
USED BY OPERATION:	#8	8 - Contour (2D chamfer)
USED BY OPERATION:	#9	9 - Contour (2D chamfer)
USED BY OPERATION:	# 10	10 - Drill/Counterbore
USED BY OPERATION:	# 11	11 - Drill/Counterbore
USED BY OPERATION:	# 12	12 - Peck Drill
USED BY OPERATION:	# 13	13 - Peck Drill
USED BY OPERATION:	# 14	14 - Contour (2D)