

GENERIC HAAS 3 - AXIS VMC

GENERAL INFORMATION


PROJECT NAME: **CUSTOMER NAME:** PROGRAMMER:

DRAWING: **REVISION:**

DATE: Friday, February 3, 2023


TIME: 8:39 PM

D:\SCHOOL\CNC\LESSON5_TUTORIAL\V2\WSHAKESPEAR_MILL LESSON 5TUT.EMCAM



COMMENTS

	<u> </u>	



STOCK: YES SHAPE: Box

SIZE: 4.0, 4.0, 1.0

RADIUS: NA

LENGTH:

AXIS: NA

FILE:

IDN: NA

C:\USERS\WES\DOCUMENTS\MY MASTERCAM

CYCLE TIME: 0 HOURS, 3 MINUTES, 38 SECONDS

OPERATION LIST

OPERATION INFO 1 - Contour (2D)

CYCLE TIME: 0 HOURS, 1 MINUTES, 1 SECONDS

COMMENT:

PROGRAM NUMBER: 0

SPINDLE SPEED: 5000 RPM FEEDRATE: 40.0 inch/min

CLEARANCE PLANE: 2.0
RETRACT PLANE: 0.2
FEED PLANE: 0.1
DEPTH: -0.008
STOCK TO LEAVE: 0.0
COMP TO TIP: YES

WORK OFFSET:




TYPE: Spot drill

NUMBER: 1
DIAMETER: 0.125
CORNER RADIUS: 0.0
LENGTH OFFSET: 1
DIAMETER OFFSET: 1
MATERIAL: HSS

NUMBER OF FLUTES: 2

FPT: 0.0002 SFM: 69.9935

MFG CODE: ASSEMBLY:



OPERATION INFO 2 - Drill/Counterbore

CYCLE TIME: 0 HOURS, 0 MINUTES, 1 SECONDS

COMMENT:

PROGRAM NUMBER: 0

SPINDLE SPEED: 5000 RPM FEEDRATE: 40.0 inch/min

CLEARANCE PLANE: 5.0

RETRACT PLANE: 0.2


FEED PLANE: 0.2

DEPTH: -0.135

STOCK TO LEAVE: 0.0

COMP TO TIP: NO

WORK OFFSET:




TOOL INFO 1/2 SPOTDRILL

TYPE: Spot drill
NUMBER: 2
DIAMETER: 0.5
CORNER RADIUS: 0.0
LENGTH OFFSET: 2
DIAMETER OFFSET: 2
MATERIAL: HSS

NUMBER OF FLUTES: 2

FPT: 0.001 SFM: 69.8953

MFG CODE: ASSEMBLY:



OPERATION INFO 3 - Drill/Counterbore

CYCLE TIME:

0 HOURS, 0 MINUTES, 2 SECONDS

COMMENT:

PROGRAM NUMBER: 0

SPINDLE SPEED: 5000 RPM FEEDRATE: 40.0 inch/min

CLEARANCE PLANE: 5.0

RETRACT PLANE: 0.2


FEED PLANE: 0.2

DEPTH: -0.3

STOCK TO LEAVE: 0.0

COMP TO TIP: NO

WORK OFFSET:




TOOL INFO 1/4 DRILL

TYPE: Drill
NUMBER: 3
DIAMETER: 0.25
CORNER RADIUS: 0.0
LENGTH OFFSET: 3
DIAMETER OFFSET: 3
MATERIAL: HSS

NUMBER OF FLUTES: 2

FPT: 0.002 SFM: 69.9607

MFG CODE: ASSEMBLY:



OPERATION INFO 4 - Pocket (Standard)

CYCLE TIME: 0 HOURS, 0 MINUTES, 10 SECONDS

COMMENT:

PROGRAM NUMBER: 0

SPINDLE SPEED: 5000 RPM FEEDRATE: 40.0 inch/min

CLEARANCE PLANE: 2.0

RETRACT PLANE: 0.25


FEED PLANE: 0.2

DEPTH: -0.125

STOCK TO LEAVE: 0.0

COMP TO TIP: YES

WORK OFFSET:



TOOL INFO 1/2 FLAT ENDMILL


TYPE: Flat endmill

NUMBER: 4
DIAMETER: 0.5
CORNER RADIUS: 0.0
LENGTH OFFSET: 4
DIAMETER OFFSET: 4
MATERIAL: HSS
NUMBER OF FLUTES: 4

1101115211 01 1 20 120.

FPT: 0.0015 SFM: 139.9215

MFG CODE: ASSEMBLY:



OPERATION INFO

5 - Contour (2D)

CYCLE TIME:

0 HOURS, 0 MINUTES, 52 SECONDS

COMMENT:


PROGRAM NUMBER:

SPINDLE SPEED: 5000 RPM FEEDRATE: 40.0 inch/min

0

CLEARANCE PLANE: 2.0 RETRACT PLANE: 0.25 0.2 FEED PLANE: DEPTH: -0.125 STOCK TO LEAVE: 0.0 COMP TO TIP: YES

WORK OFFSET:



TOOL INFO 1/2 FLAT ENDMILL


TYPE: Flat endmill NUMBER: 4 DIAMETER: 0.5 **CORNER RADIUS:** 0.0 LENGTH OFFSET: 4

DIAMETER OFFSET: 4 MATERIAL: HSS 4

NUMBER OF FLUTES:

FPT: 0.0015 SFM: 139.9215

MFG CODE: ASSEMBLY:



OPERATION INFO

6 - Contour (2D)

CYCLE TIME:

0 HOURS, 0 MINUTES, 30 SECONDS

COMMENT:

PROGRAM NUMBER:

SPINDLE SPEED: 5000 RPM FEEDRATE: 40.0 inch/min

0

CLEARANCE PLANE: 2.0

RETRACT PLANE: 0.25


FEED PLANE: 0.2

DEPTH: -0.25

STOCK TO LEAVE: 0.0

COMP TO TIP: YES

WORK OFFSET:




TOOL INFO 1/2 FLAT ENDMILL

TYPE: Flat endmill
NUMBER: 4
DIAMETER: 0.5
CORNER RADIUS: 0.0
LENGTH OFFSET: 4
DIAMETER OFFSET: 4
MATERIAL: HSS

NUMBER OF FLUTES: 4

FPT: 0.0015 SFM: 139.9215

MFG CODE: ASSEMBLY:



OPERATION INFO 7 - Contour (2D chamfer)

CYCLE TIME: 0 HOURS, 0 MINUTES, 22 SECONDS


COMMENT:

PROGRAM NUMBER: 0

SPINDLE SPEED: 5000 RPM FEEDRATE: 40.0 inch/min

CLEARANCE PLANE: 2.0
RETRACT PLANE: 0.25
FEED PLANE: 0.2
DEPTH: 0.0
STOCK TO LEAVE: 0.0
COMP TO TIP: YES

WORK OFFSET:




TOOL INFO 1/2 SPOTDRILL

TYPE: Spot drill
NUMBER: 2
DIAMETER: 0.5
CORNER RADIUS: 0.0
LENGTH OFFSET: 2
DIAMETER OFFSET: 2
MATERIAL: HSS

NUMBER OF FLUTES: 2

FPT: 0.001 SFM: 69.8953

MFG CODE: ASSEMBLY:



OPERATION INFO 8 - Contour (2D chamfer)

CYCLE TIME: 0 HOURS, 0 MINUTES, 11 SECONDS

COMMENT:

PROGRAM NUMBER: 0

SPINDLE SPEED: 5000 RPM FEEDRATE: 40.0 inch/min

CLEARANCE PLANE: 2.0

RETRACT PLANE: 0.25


FEED PLANE: 0.2

DEPTH: 0.0

STOCK TO LEAVE: 0.0

COMP TO TIP: YES

WORK OFFSET:




TOOL INFO 1/2 SPOTDRILL

TYPE: Spot drill
NUMBER: 2
DIAMETER: 0.5
CORNER RADIUS: 0.0
LENGTH OFFSET: 2
DIAMETER OFFSET: 2
MATERIAL: HSS

NUMBER OF FLUTES: 2

FPT: 0.001 SFM: 69.8953

MFG CODE: ASSEMBLY:



OPERATION INFO 9 - Contour (2D chamfer)

CYCLE TIME: 0 HOURS, 0 MINUTES, 25 SECONDS

COMMENT:

PROGRAM NUMBER: 0

SPINDLE SPEED: 5000 RPM FEEDRATE: 40.0 inch/min

CLEARANCE PLANE: 2.0

RETRACT PLANE: 0.25


FEED PLANE: 0.2

DEPTH: -0.125

STOCK TO LEAVE: 0.0

COMP TO TIP: YES

WORK OFFSET:




TOOL INFO 1/2 SPOTDRILL

TYPE: Spot drill
NUMBER: 2
DIAMETER: 0.5
CORNER RADIUS: 0.0
LENGTH OFFSET: 2
DIAMETER OFFSET: 2
MATERIAL: HSS

NUMBER OF FLUTES: 2

FPT: 0.001 SFM: 69.8953

MFG CODE: ASSEMBLY:



TOOL LIST Sorted: NO

TOOL INFO 1/8 SPOTDRILL


TYPE: Spot drill NUMBER: 1 DIAMETER: 0.125 CORNER RADIUS: 0.0 LENGTH OFFSET: 1 DIAMETER OFFSET: 1 MATERIAL: HSS NUMBER OF FLUTES: 2

FPT: 0.0002 SFM: 69.9935

MFG CODE: ASSEMBLY:

HOLDER: Default Holder

TIME: 00:01:01



USED BY OPERATION: #1 1 - Contour (2D)

TOOL INFO 1/2 SPOTDRILL

TYPE: Spot drill NUMBER: 2 DIAMETER: 0.5 **CORNER RADIUS:** 0.0 LENGTH OFFSET: 2 DIAMETER OFFSET: 2 HSS MATERIAL: NUMBER OF FLUTES: 2

FPT: 0.001 SFM: 69.8953

MFG CODE: ASSEMBLY:

HOLDER: Default Holder TIME: 00:01:01

-2.000 1.000 4.000 3.000

USED BY OPERATION: #2 2 - Drill/Counterbore
USED BY OPERATION: #7 7 - Contour (2D chamfer)
USED BY OPERATION: #8 8 - Contour (2D chamfer)
USED BY OPERATION: #9 9 - Contour (2D chamfer)


TOOL INFO 1/4 DRILL

TYPE: Drill
NUMBER: 3
DIAMETER: 0.25
CORNER RADIUS: 0.0
LENGTH OFFSET: 3
DIAMETER OFFSET: 3
MATERIAL: HSS
NUMBER OF FLUTES: 2

FPT: 0.002 SFM: 69.9607

MFG CODE: ASSEMBLY:

HOLDER: Default Holder TIME: 00:00:02



USED BY OPERATION: #3 3 - Drill/Counterbore

TOOL INFO 1/2 FLAT ENDMILL

TYPE: Flat endmill

NUMBER: 4
DIAMETER: 0.5
CORNER RADIUS: 0.0
LENGTH OFFSET: 4
DIAMETER OFFSET: 4
MATERIAL: HSS
NUMBER OF FLUTES: 4

FPT: 0.0015 SFM: 139.9215

MFG CODE: ASSEMBLY:

HOLDER: Default Holder TIME: 00:01:33

7.000 1.000 4.000 3.000

USED BY OPERATION: #4 4 - Pocket (Standard)
USED BY OPERATION: #5 5 - Contour (2D)
USED BY OPERATION: #6 6 - Contour (2D)

WORK OFFSETS

OFFSET INFO

NUMBER: PLAN	E: Top	ORIGIN: 0.0, 0.0, 0.0
USED BY OPERATION:	# 1	1 - Contour (2D)
USED BY OPERATION:	#2	2 - Drill/Counterbore
USED BY OPERATION:	#3	3 - Drill/Counterbore
USED BY OPERATION:	#4	4 - Pocket (Standard)
USED BY OPERATION:	#5	5 - Contour (2D)
USED BY OPERATION:	#6	6 - Contour (2D)
USED BY OPERATION:	#7	7 - Contour (2D chamfer)
USED BY OPERATION:	#8	8 - Contour (2D chamfer)
USED BY OPERATION:	#9	9 - Contour (2D chamfer)