

# Setup Sheet Report

## GENERIC HAAS 3 - AXIS VMC

#### **GENERAL INFORMATION**


PROJECT NAME: CUSTOMER NAME: PROGRAMMER:

DRAWING: REVISION:

DATE: Tuesday, March 7, 2023

TIME: 4:20 PM

## C:\USERS\WESTONSHAKESPEAR\DOWNLOADS\WSHAKESPEAR\_MILL 8A.EMCAM






1.0681 in Inch

COMMENTS		

STOCK



STOCK: YES

SHAPE: Box

SIZE: 6.25, 4.25, 1.0

RADIUS: NA

LENGTH:

AXIS: NA

FILE:

IDN: NA

## C:\USERS\WESTONSHAKESPEAR\DOCUMENTS\MY

CYCLE TIME: 0 HOURS, 48 MINUTES, 50 SECONDS

#### **OPERATION LIST**

OPERATION INFO 1 - Facing

CYCLE TIME: 0 HOURS, 2 MINUTES, 16 SECONDS

COMMENT:

PROGRAM NUMBER: 33013

SPINDLE SPEED: 4966 RPM FEEDRATE: 49.0 inch/min

CLEARANCE PLANE: 2.0
RETRACT PLANE: 0.125
FEED PLANE: 0.05
DEPTH: 0.0

STOCK TO LEAVE: 0.0 0.02 COMP TO TIP: YES

WORK OFFSET: 0





TYPE: Flat endmill

NUMBER: 1
DIAMETER: 0.375
CORNER RADIUS: 0.0
LENGTH OFFSET: 1
DIAMETER OFFSET: 1
MATERIAL: HSS
NUMBER OF FLUTES: 4

FPT: 0.0011 SFM: 139.9869

MFG CODE: ASSEMBLY:





## OPERATION INFO 2 - 2D High Speed (2D Dynamic Mill)

CYCLE TIME: 0 HOURS, 1 MINUTES, 26 SECONDS

COMMENT:


PROGRAM NUMBER: 33013

SPINDLE SPEED: 4966 RPM FEEDRATE: 49.0 inch/min

CLEARANCE PLANE: 0.0
RETRACT PLANE: 0.125
FEED PLANE: 0.05
DEPTH: 0.0

STOCK TO LEAVE: 0.0 0.02 COMP TO TIP: YES

WORK OFFSET: 0




## TOOL INFO 3/8 FLAT ENDMILL

TYPE: Flat endmill

NUMBER: 1
DIAMETER: 0.375
CORNER RADIUS: 0.0
LENGTH OFFSET: 1
DIAMETER OFFSET: 1
MATERIAL: HSS
NUMBER OF FLUTES: 4

FPT: 0.0011 SFM: 139.9869

MFG CODE: ASSEMBLY:



## OPERATION INFO 3 - 2D High Speed (2D Dynamic Rest Mill)

CYCLE TIME: 0 HOURS, 5 MINUTES, 20 SECONDS

COMMENT:

PROGRAM NUMBER: 33013

SPINDLE SPEED: 4966 RPM FEEDRATE: 49.0 inch/min

CLEARANCE PLANE: 0.0


RETRACT PLANE: 0.125

FEED PLANE: 0.05

DEPTH: 0.0

STOCK TO LEAVE: 0.0 0.01 COMP TO TIP: YES

WORK OFFSET: 0




## TOOL INFO 3/8 FLAT ENDMILL

TYPE: Flat endmill

NUMBER: 1
DIAMETER: 0.375
CORNER RADIUS: 0.0
LENGTH OFFSET: 1
DIAMETER OFFSET: 1
MATERIAL: HSS
NUMBER OF FLUTES: 4

FPT: 0.0011 SFM: 139.9869

MFG CODE: ASSEMBLY:



#### OPERATION INFO 4 - Pocket (Standard)

CYCLE TIME: 0 HOURS, 0 MINUTES, 26 SECONDS

COMMENT:

PROGRAM NUMBER: 33013

SPINDLE SPEED: 4966 RPM FEEDRATE: 18.0 inch/min

CLEARANCE PLANE: 2.0

RETRACT PLANE: 0.25

FEED PLANE: 0.2

DEPTH: 0.0

STOCK TO LEAVE: 0.0 0.01 COMP TO TIP: YES

WORK OFFSET: 0




TYPE: Flat endmill

NUMBER: 2
DIAMETER: 0.25
CORNER RADIUS: 0.0
LENGTH OFFSET: 2
DIAMETER OFFSET: 2
MATERIAL: HSS
NUMBER OF FLUTES: 4

FPT: 0.0008 SFM: 139.9869

MFG CODE: ASSEMBLY:



## OPERATION INFO 5 - 2D High Speed (2D Dynamic Rest Mill)

CYCLE TIME: 0 HOURS, 1 MINUTES, 15 SECONDS

COMMENT:

PROGRAM NUMBER: 33013

SPINDLE SPEED: 4996 RPM FEEDRATE: 18.0 inch/min

CLEARANCE PLANE: 0.0

RETRACT PLANE: 0.25

FEED PLANE: 0.1

DEPTH: 0.0

STOCK TO LEAVE: 0.0

COMP TO TIP: YES

WORK OFFSET: 0




## TOOL INFO 1/4 FLAT ENDMILL

TYPE: Flat endmill

NUMBER: 2
DIAMETER: 0.25
CORNER RADIUS: 0.0
LENGTH OFFSET: 2
DIAMETER OFFSET: 2
MATERIAL: HSS
NUMBER OF FLUTES: 4

FPT: 0.0008 SFM: 139.9869

MFG CODE: ASSEMBLY:



## OPERATION INFO 6 - Contour (2D)

CYCLE TIME: 0 HOURS, 1 MINUTES, 5 SECONDS

COMMENT:

PROGRAM NUMBER: 33013

SPINDLE SPEED: 4966 RPM FEEDRATE: 18.0 inch/min

CLEARANCE PLANE: 2.0
RETRACT PLANE: 0.2
FEED PLANE: 0.1
DEPTH: 0.0
STOCK TO LEAVE: 0.0
COMP TO TIP: YES

WORK OFFSET: 0




## TOOL INFO 1/4 FLAT ENDMILL

TYPE: Flat endmill

NUMBER: 2
DIAMETER: 0.25
CORNER RADIUS: 0.0
LENGTH OFFSET: 2
DIAMETER OFFSET: 2
MATERIAL: HSS
NUMBER OF FLUTES: 4

FPT: 0.0008 SFM: 139.9869

MFG CODE: ASSEMBLY:



## OPERATION INFO 7 - Contour (2D)

CYCLE TIME:

0 HOURS, 1 MINUTES, 5 SECONDS

COMMENT:

PROGRAM NUMBER: 33013

SPINDLE SPEED: 4966 RPM FEEDRATE: 18.0 inch/min

CLEARANCE PLANE: 2.0

RETRACT PLANE: 0.2

FEED PLANE: 0.1

DEPTH: 0.0

STOCK TO LEAVE: 0.0

COMP TO TIP: YES

WORK OFFSET: 0




## TOOL INFO 1/4 FLAT ENDMILL

TYPE: Flat endmill

NUMBER: 2
DIAMETER: 0.25
CORNER RADIUS: 0.0
LENGTH OFFSET: 2
DIAMETER OFFSET: 2
MATERIAL: HSS
NUMBER OF FLUTES: 4

FPT: 0.0008 SFM: 139.9869

MFG CODE: ASSEMBLY:



## OPERATION INFO 8 - Contour (2D)

CYCLE TIME: 0 HOURS, 0 MINUTES, 9 SECONDS

COMMENT:

PROGRAM NUMBER: 33013

SPINDLE SPEED: 4966 RPM FEEDRATE: 20.0 inch/min

CLEARANCE PLANE: 2.0

RETRACT PLANE: 0.2

FEED PLANE: 0.1

DEPTH: 0.0

STOCK TO LEAVE: 0.0

COMP TO TIP: YES

WORK OFFSET: 0




TYPE: Flat endmill

NUMBER: 2
DIAMETER: 0.25
CORNER RADIUS: 0.0
LENGTH OFFSET: 2
DIAMETER OFFSET: 2
MATERIAL: HSS
NUMBER OF FLUTES: 4

FPT: 0.0008 SFM: 139.9869

MFG CODE: ASSEMBLY:

TOOL INFO



#### OPERATION INFO 9 - Contour (2D chamfer)

CYCLE TIME: 0 HOURS, 17 MINUTES, 24 SECONDS


COMMENT:

PROGRAM NUMBER: 33013

SPINDLE SPEED: 534 RPM

1.0696 inch/min

FEEDRATE: CLEARANCE PLANE: 2.0 RETRACT PLANE: 0.2 FEED PLANE: 0.1 DEPTH: 0.0 STOCK TO LEAVE: 0.0 COMP TO TIP: YES WORK OFFSET: 0




#### TOOL INFO 1/2 SPOTDRILL

Spot drill TYPE: NUMBER: 3 DIAMETER: 0.5 CORNER RADIUS: 0.0 LENGTH OFFSET: 3 DIAMETER OFFSET: 3 MATERIAL: HSS NUMBER OF FLUTES: 2

FPT: 0.001 SFM: 69.8953

MFG CODE: ASSEMBLY:

HOLDER: Default Holder TIME: 00:17:24



## OPERATION INFO 10 - Contour (2D chamfer)

CYCLE TIME: 0 HOURS, 14 MINUTES, 56 SECONDS


COMMENT:

PROGRAM NUMBER: 33013

SPINDLE SPEED: 534 RPM

FEEDRATE: 1.0696 inch/min

CLEARANCE PLANE: 2.0
RETRACT PLANE: 0.2
FEED PLANE: 0.1
DEPTH: 0.0
STOCK TO LEAVE: 0.0
COMP TO TIP: YES
WORK OFFSET: 0




## TOOL INFO 1/2 SPOTDRILL

Spot drill TYPE: NUMBER: 3 0.5 DIAMETER: 0.0 **CORNER RADIUS:** LENGTH OFFSET: 3 DIAMETER OFFSET: 3 MATERIAL: HSS NUMBER OF FLUTES: 2

FPT: 0.001 SFM: 69.8953

MFG CODE: ASSEMBLY:



#### OPERATION INFO 11 - Contour (2D chamfer)

CYCLE TIME: 0 HOURS, 2 MINUTES, 36 SECONDS


COMMENT:

PROGRAM NUMBER: 33013

SPINDLE SPEED: 534 RPM

FEEDRATE: 1.0696 inch/min

CLEARANCE PLANE: 2.0 RETRACT PLANE: 0.2 FEED PLANE: 0.1 DEPTH: 0.0 STOCK TO LEAVE: 0.0 COMP TO TIP: YES WORK OFFSET: 0




#### TOOL INFO 1/2 SPOTDRILL

Spot drill TYPE: NUMBER: 3 DIAMETER: 0.5 CORNER RADIUS: 0.0 LENGTH OFFSET: 3 DIAMETER OFFSET: 3 MATERIAL: HSS NUMBER OF FLUTES: 2

FPT: 0.001 SFM: 69.8953

MFG CODE: ASSEMBLY:



#### OPERATION INFO 12 - Drill/Counterbore

CYCLE TIME: 0 HO

COMMENT:

0 HOURS, 0 MINUTES, 1 SECONDS

PROGRAM NUMBER:

33013

SPINDLE SPEED:

4966 RPM

FEEDRATE:

49.0 inch/min

CLEARANCE PLANE: RETRACT PLANE:

5.0

FEED PLANE:

0.125 0.125

DEPTH:

-0.1925

STOCK TO LEAVE:

COMP TO TIP:

0.0

NO

WORK OFFSET:

0

#### TOOL INFO

## 1/2 SPOTDRILL

TYPE: Spot drill NUMBER: 3

DIAMETER: 0.5 CORNER RADIUS: 0.0

LENGTH OFFSET: 3


DIAMETER OFFSET: 3
MATERIAL: HSS


NUMBER OF FLUTES: 2

FPT: 0.001 SFM: 69.8953

MFG CODE:

ASSEMBLY:





## OPERATION INFO 13 - Contour (2D)

CYCLE TIME:

0 HOURS, 0 MINUTES, 40 SECONDS

COMMENT:

PROGRAM NUMBER: 0

SPINDLE SPEED: 4966 RPM FEEDRATE: 25.0 inch/min

CLEARANCE PLANE: 2.0

RETRACT PLANE: 0.2

FEED PLANE: 0.1

DEPTH: -0.02

STOCK TO LEAVE: 0.0

COMP TO TIP: YES

WORK OFFSET: 0



## TOOL INFO 1/8 SPOTDRILL


TYPE: Spot drill
NUMBER: 4
DIAMETER: 0.125
CORNER RADIUS: 0.0
LENGTH OFFSET: 4
DIAMETER OFFSET: 4
MATERIAL: HSS

FPT: 0.0002 SFM: 69.9935

2

MFG CODE: ASSEMBLY:

NUMBER OF FLUTES:



#### OPERATION INFO 14 - Drill/Counterbore

CYCLE TIME: 0 HOURS, 0 MINUTES, 4 SECONDS

COMMENT:

PROGRAM NUMBER: 33013

SPINDLE SPEED: 5000 RPM FEEDRATE: 40.0 inch/min

CLEARANCE PLANE: 5.0


RETRACT PLANE: 0.125

FEED PLANE: 0.125

DEPTH: -0.0938

STOCK TO LEAVE: 0.0 COMP TO TIP: NO

WORK OFFSET: 0




#### TOOL INFO 3/8 DRILL

TYPE: Drill NUMBER: 5 DIAMETER: 0.375 CORNER RADIUS: 0.0 LENGTH OFFSET: 5 DIAMETER OFFSET: 5 MATERIAL: HSS NUMBER OF FLUTES: 2

FPT: 0.003 SFM: 69.9935

MFG CODE: ASSEMBLY:



TOOL LIST Sorted: NO

#### TOOL INFO 3/8 FLAT ENDMILL

TYPE: Flat endmill
NUMBER: 1
DIAMETER: 0.375
CORNER RADIUS: 0.0
LENGTH OFFSET: 1
DIAMETER OFFSET: 1
MATERIAL: HSS

FPT: 0.0011 SFM: 139.9869

4

MFG CODE: ASSEMBLY:

NUMBER OF FLUTES:

HOLDER: Default Holder TIME: 00:09:02

USED BY OPERATION: #1 1 - Facing

USED BY OPERATION: #2 2 - 2D High Speed (2D Dynamic Mill)
USED BY OPERATION: #3 3 - 2D High Speed (2D Dynamic Rest Mill)

#### TOOL INFO 1/4 FLAT ENDMILL

TYPE: Flat endmill
NUMBER: 2
DIAMETER: 0.25
CORNER RADIUS: 0.0
LENGTH OFFSET: 2
DIAMETER OFFSET: 2
MATERIAL: HSS
NUMBER OF FLUTES: 4

FPT: 0.0008 SFM: 139.9869


MFG CODE: ASSEMBLY:


HOLDER: Default Holder TIME: 00:04:03

USED BY OPERATION: #4 4 - Pocket (Standard)

USED BY OPERATION: #5 5 - 2D High Speed (2D Dynamic Rest Mill)

USED BY OPERATION: #6 6 - Contour (2D)
USED BY OPERATION: #7 7 - Contour (2D)
USED BY OPERATION: #8 8 - Contour (2D)





#### TOOL INFO

#### 1/2 SPOTDRILL

TYPE: Spot drill NUMBER: 3 DIAMETER: 0.5 CORNER RADIUS: 0.0 LENGTH OFFSET: 3 DIAMETER OFFSET: 3 MATERIAL: HSS NUMBER OF FLUTES: 2

FPT: 0.001 SFM: 69.8953

MFG CODE: ASSEMBLY:

HOLDER: Default Holder TIME: 00:34:59

USED BY OPERATION: #9 9 - Contour (2D chamfer)
USED BY OPERATION: #10 10 - Contour (2D chamfer)
USED BY OPERATION: #11 11 - Contour (2D chamfer)
USED BY OPERATION: #12 12 - Drill/Counterbore

#### TOOL INFO 1/8 SPOTDRILL


TYPE: Spot drill
NUMBER: 4
DIAMETER: 0.125
CORNER RADIUS: 0.0
LENGTH OFFSET: 4
DIAMETER OFFSET: 4
MATERIAL: HSS
NUMBER OF FLUTES: 2


FPT: 0.0002 SFM: 69.9935

MFG CODE: ASSEMBLY:

HOLDER: Default Holder TIME: 00:00:40

USED BY OPERATION: #13 13 - Contour (2D)





TOOL INFO 3/8 DRILL


TYPE: Drill
NUMBER: 5
DIAMETER: 0.375
CORNER RADIUS: 0.0
LENGTH OFFSET: 5
DIAMETER OFFSET: 5
MATERIAL: HSS
NUMBER OF FLUTES: 2

FPT: 0.003 SFM: 69.9935

MFG CODE: ASSEMBLY:

HOLDER: Default Holder TIME: 00:00:04

USED BY OPERATION: # 14 14 - Drill/Counterbore



## **WORK OFFSETS**

## OFFSET INFO

NUMBER: 0 PLANE	≣: Тор	ORIGIN: 0.0, 0.0, 0.0
USED BY OPERATION:	# 1	1 - Facing
USED BY OPERATION:	#2	2 - 2D High Speed (2D Dynamic Mill)
USED BY OPERATION:	#3	3 - 2D High Speed (2D Dynamic Rest Mill)
USED BY OPERATION:	#4	4 - Pocket (Standard)
USED BY OPERATION:	# 5	5 - 2D High Speed (2D Dynamic Rest Mill)
USED BY OPERATION:	#6	6 - Contour (2D)
USED BY OPERATION:	#7	7 - Contour (2D)
USED BY OPERATION:	#8	8 - Contour (2D)
USED BY OPERATION:	#9	9 - Contour (2D chamfer)
USED BY OPERATION:	# 10	10 - Contour (2D chamfer)
USED BY OPERATION:	# 11	11 - Contour (2D chamfer)
USED BY OPERATION:	# 12	12 - Drill/Counterbore
USED BY OPERATION:	# 13	13 - Contour (2D)
USED BY OPERATION:	# 14	14 - Drill/Counterbore