

Setup Sheet Report

GENERIC HAAS 3 - AXIS VMC

GENERAL INFORMATION				
PROJECT NAME: CUSTOMER NAME: PROGRAMMER: DRAWING: DATE: TIME:	REVISION: Thursday, February 23, 2023 9:48 AM			
C:\USERS\WESTONSHAKESPEAR\DOWNLOADS\WSHAKESPEAR_MILL LESSON 6.EMCAM				
COMMENTS				

STOCK: YES

SHAPE: Box

SIZE: 4.5, 4.5, 0.5

RADIUS: NA

LENGTH:

AXIS: NA

FILE:

IDN: NA

C:\USERS\WESTONSHAKESPEAR\DOCUMENTS\MY

CYCLE TIME: 0 HOURS, 7 MINUTES, 36 SECONDS

OPERATION LIST

OPERATION INFO 3 - 2D High Speed (2D Area Mill)

CYCLE TIME:

0 HOURS, 1 MINUTES, 59 SECONDS

COMMENT:

PROGRAM NUMBER: 33012

SPINDLE SPEED: 4966 RPM FEEDRATE: 49.0 inch/min

CLEARANCE PLANE: 0.125
RETRACT PLANE: 0.125
FEED PLANE: 0.05
DEPTH: -0.125
STOCK TO LEAVE: 0.0 0.02
COMP TO TIP: YES
WORK OFFSET: 0


TOOL INFO 1/2 FLAT ENDMILL

TYPE: Flat endmill

NUMBER: 1
DIAMETER: 0.5
CORNER RADIUS: 0.0
LENGTH OFFSET: 1
DIAMETER OFFSET: 1
MATERIAL: HSS
NUMBER OF FLUTES: 4

FPT: 0.0131 SFM: 300.0

MFG CODE: ASSEMBLY:



OPERATION INFO 4 - 2D High Speed (2D Area Mill)

CYCLE TIME: 0 HOURS, 0 MINUTES, 19 SECONDS

COMMENT:

PROGRAM NUMBER: 33012

SPINDLE SPEED: 4966 RPM FEEDRATE: 49.0 inch/min

CLEARANCE PLANE: 0.125
RETRACT PLANE: 0.125
FEED PLANE: 0.05
DEPTH: -0.375
STOCK TO LEAVE: 0.0 0.02
COMP TO TIP: YES
WORK OFFSET: 0

TOOL INFO 1/2 FLAT ENDMILL


TYPE: Flat endmill
NUMBER: 1
DIAMETER: 0.5
CORNER RADIUS: 0.0
LENGTH OFFSET: 1
DIAMETER OFFSET: 1
MATERIAL: HSS
NUMBER OF FLUTES: 4

FPT: 0.0131 SFM: 300.0

MFG CODE: ASSEMBLY:

HOLDER: Default Holder

TIME: 00:00:19



OPERATION INFO 5 - 2D High Speed (2D Area Mill)

CYCLE TIME: 0 HOURS, 0 MINUTES, 19 SECONDS

COMMENT:

PROGRAM NUMBER: 33012

SPINDLE SPEED: 4966 RPM FEEDRATE: 49.0 inch/min

CLEARANCE PLANE: 2.0

RETRACT PLANE: 0.125

FEED PLANE: 0.05

DEPTH: -0.375

STOCK TO LEAVE: 0.0 0.02

COMP TO TIP: YES

WORK OFFSET: 0


TOOL INFO 1/2 FLAT ENDMILL

TYPE: Flat endmill
NUMBER: 1
DIAMETER: 0.5
CORNER RADIUS: 0.0
LENGTH OFFSET: 1
DIAMETER OFFSET: 1
MATERIAL: HSS

NUMBER OF FLUTES: 4

FPT: 0.0131 SFM: 300.0

MFG CODE: ASSEMBLY:



OPERATION INFO 6 - 2D High Speed (2D Area Mill)

CYCLE TIME: 0 HOURS, 0 MINUTES, 23 SECONDS

COMMENT:

PROGRAM NUMBER: 33012

SPINDLE SPEED: 4966 RPM FEEDRATE: 49.0 inch/min

CLEARANCE PLANE: 2.0

RETRACT PLANE: 0.125

FEED PLANE: 0.05

DEPTH: -0.45

STOCK TO LEAVE: 0.0 0.02

COMP TO TIP: YES


WORK OFFSET: 0

TOOL INFO 1/2 FLAT ENDMILL

TYPE: Flat endmill
NUMBER: 1
DIAMETER: 0.5
CORNER RADIUS: 0.0
LENGTH OFFSET: 1
DIAMETER OFFSET: 1
MATERIAL: HSS
NUMBER OF FLUTES: 4

FPT: 0.0131 SFM: 300.0

MFG CODE: ASSEMBLY:



OPERATION INFO 7 - Pocket (Standard)

CYCLE TIME: 0 HOURS, 0 MINUTES, 8 SECONDS

COMMENT:

PROGRAM NUMBER: 33012

SPINDLE SPEED: 4966 RPM FEEDRATE: 60.0 inch/min

CLEARANCE PLANE: 2.0

RETRACT PLANE: 0.125

FEED PLANE: 0.05

DEPTH: -0.125

STOCK TO LEAVE: 0.0

COMP TO TIP: YES

WORK OFFSET: 0


TOOL INFO 1/2 FLAT ENDMILL

TYPE: Flat endmill
NUMBER: 1
DIAMETER: 0.5
CORNER RADIUS: 0.0
LENGTH OFFSET: 1
DIAMETER OFFSET: 1
MATERIAL: HSS

NUMBER OF FLUTES: 4

FPT: 0.0131 SFM: 300.0

MFG CODE: ASSEMBLY:



OPERATION INFO 8 - Pocket (Standard)

CYCLE TIME: 0 HOURS, 0 MINUTES, 4 SECONDS

COMMENT:

PROGRAM NUMBER: 33012

SPINDLE SPEED: 4966 RPM FEEDRATE: 60.0 inch/min

CLEARANCE PLANE: 2.0

RETRACT PLANE: 0.125

FEED PLANE: 0.05

DEPTH: -0.375

STOCK TO LEAVE: 0.0

COMP TO TIP: YES


WORK OFFSET: 0

TOOL INFO 1/2 FLAT ENDMILL

TYPE: Flat endmill
NUMBER: 1
DIAMETER: 0.5
CORNER RADIUS: 0.0
LENGTH OFFSET: 1
DIAMETER OFFSET: 1
MATERIAL: HSS
NUMBER OF FLUTES: 4

FPT: 0.0131 SFM: 300.0

MFG CODE: ASSEMBLY:



OPERATION INFO 9 - Pocket (Standard)

CYCLE TIME: 0 HOURS, 0 MINUTES, 4 SECONDS

COMMENT:

PROGRAM NUMBER: 33012

SPINDLE SPEED: 4966 RPM FEEDRATE: 60.0 inch/min

CLEARANCE PLANE: 2.0

RETRACT PLANE: 0.125

FEED PLANE: 0.05

DEPTH: -0.375

STOCK TO LEAVE: 0.0

COMP TO TIP: YES

WORK OFFSET: 0

TOOL INFO 1/2 FLAT ENDMILL

TYPE: Flat endmill
NUMBER: 1
DIAMETER: 0.5
CORNER RADIUS: 0.0
LENGTH OFFSET: 1
DIAMETER OFFSET: 1
MATERIAL: HSS


NUMBER OF FLUTES: 4

FPT: 0.0131

MFG CODE: ASSEMBLY:

HOLDER: Default Holder TIME: 00:00:04

SFM: 300.0



OPERATION INFO 10 - Pocket (Standard)

CYCLE TIME: 0 HOURS, 0 MINUTES, 3 SECONDS

COMMENT:

PROGRAM NUMBER: 33012

SPINDLE SPEED: 4966 RPM FEEDRATE: 60.0 inch/min

CLEARANCE PLANE: 2.0

RETRACT PLANE: 0.125

FEED PLANE: 0.05

DEPTH: -0.45

STOCK TO LEAVE: 0.0

COMP TO TIP: YES


WORK OFFSET: 0

TOOL INFO 1/2 FLAT ENDMILL

TYPE: Flat endmill
NUMBER: 1
DIAMETER: 0.5
CORNER RADIUS: 0.0
LENGTH OFFSET: 1
DIAMETER OFFSET: 1
MATERIAL: HSS
NUMBER OF FLUTES: 4

FPT: 0.0131 SFM: 300.0

MFG CODE: ASSEMBLY:



OPERATION INFO 11 - 2D High Speed (2D Dynamic Mill)

CYCLE TIME: 0 HOURS, 0 MINUTES, 21 SECONDS

COMMENT:

PROGRAM NUMBER: 33012

SPINDLE SPEED: 4966 RPM FEEDRATE: 49.0 inch/min

CLEARANCE PLANE: 2.0
RETRACT PLANE: 1.0
FEED PLANE: 0.05
DEPTH: -0.5
STOCK TO LEAVE: 0.0 0.02
COMP TO TIP: YES

WORK OFFSET: 0


TOOL INFO 3/8 FLAT ENDMILL

TYPE: Flat endmill

NUMBER: 2
DIAMETER: 0.375
CORNER RADIUS: 0.0
LENGTH OFFSET: 2
DIAMETER OFFSET: 2
MATERIAL: HSS
NUMBER OF FLUTES: 4

FPT: 0.0011 SFM: 139.9869

MFG CODE: ASSEMBLY:



OPERATION INFO 12 - Contour (2D)

CYCLE TIME: 0 HOURS, 0 MINUTES, 44 SECONDS

COMMENT:

PROGRAM NUMBER: 33012

SPINDLE SPEED: 4966 RPM FEEDRATE: 60.0 inch/min

CLEARANCE PLANE: 2.0

RETRACT PLANE: 0.125

FEED PLANE: 0.05

DEPTH: -0.5

STOCK TO LEAVE: 0.0

COMP TO TIP: YES

WORK OFFSET: 0


TOOL INFO 3/8 FLAT ENDMILL

TYPE: Flat endmill

NUMBER: 2
DIAMETER: 0.375
CORNER RADIUS: 0.0
LENGTH OFFSET: 2
DIAMETER OFFSET: 2
MATERIAL: HSS
NUMBER OF FLUTES: 4

FPT: 0.0011 SFM: 139.9869

MFG CODE: ASSEMBLY:



OPERATION INFO 13 - Contour (2D chamfer)

CYCLE TIME: 0 HOURS, 0 MINUTES, 38 SECONDS

COMMENT:

PROGRAM NUMBER: 33012

SPINDLE SPEED: 4966 RPM FEEDRATE: 49.0 inch/min

CLEARANCE PLANE: 2.0

RETRACT PLANE: 0.125

FEED PLANE: 0.05

DEPTH: 0.0

STOCK TO LEAVE: 0.0

COMP TO TIP: YES

WORK OFFSET: 0


TOOL INFO 1/2 SPOTDRILL

TYPE: Spot drill
NUMBER: 3
DIAMETER: 0.5
CORNER RADIUS: 0.0
LENGTH OFFSET: 3
DIAMETER OFFSET: 3
MATERIAL: HSS

NUMBER OF FLUTES: 2

FPT: 0.001 SFM: 69.8953

MFG CODE: ASSEMBLY:



OPERATION INFO 14 - Contour (2D chamfer)

CYCLE TIME: 0 HOURS, 0 MINUTES, 13 SECONDS

COMMENT:

PROGRAM NUMBER: 33012

SPINDLE SPEED: 4966 RPM FEEDRATE: 49.0 inch/min

CLEARANCE PLANE: 2.0

RETRACT PLANE: 0.125

FEED PLANE: 0.05

DEPTH: 0.0

STOCK TO LEAVE: 0.0

COMP TO TIP: YES


WORK OFFSET: 0

TOOL INFO 1/2 SPOTDRILL

TYPE: Spot drill NUMBER: 3 0.5 DIAMETER: **CORNER RADIUS:** 0.0 LENGTH OFFSET: 3 DIAMETER OFFSET: 3 MATERIAL: HSS NUMBER OF FLUTES: 2

FPT: 0.001 SFM: 69.8953

MFG CODE: ASSEMBLY:



OPERATION INFO 15 - Drill/Counterbore

CYCLE TIME: 0 HOURS, 0 MINUTES, 2 SECONDS

COMMENT:

PROGRAM NUMBER: 33012

SPINDLE SPEED: 4966 RPM 49.0 inch/min FEEDRATE:

CLEARANCE PLANE: 2.0 RETRACT PLANE: 0.125 FEED PLANE: 0.125 DEPTH: -0.0988 STOCK TO LEAVE: 0.0 COMP TO TIP: NO WORK OFFSET: 0


TOOL INFO 1/2 SPOTDRILL

TYPE: Spot drill NUMBER: 3 0.5 DIAMETER: **CORNER RADIUS:** 0.0 LENGTH OFFSET: 3 DIAMETER OFFSET: 3 MATERIAL: HSS 2

NUMBER OF FLUTES:

FPT: 0.001 SFM: 69.8953

MFG CODE: ASSEMBLY:



OPERATION INFO 16 - Drill/Counterbore

CYCLE TIME: 0 HOURS, 0 MINUTES, 2 SECONDS

COMMENT:

PROGRAM NUMBER: 33012

SPINDLE SPEED: 4966 RPM FEEDRATE: 49.0 inch/min

CLEARANCE PLANE: 2.125

RETRACT PLANE: 0.125

FEED PLANE: 0.125

DEPTH: -0.1925

STOCK TO LEAVE: 0.0

COMP TO TIP: NO


WORK OFFSET: 0

TOOL INFO 1/2 SPOTDRILL

TYPE: Spot drill NUMBER: 3 0.5 DIAMETER: **CORNER RADIUS:** 0.0 LENGTH OFFSET: 3 DIAMETER OFFSET: 3 MATERIAL: HSS NUMBER OF FLUTES: 2

FPT: 0.001 SFM: 69.8953

MFG CODE: ASSEMBLY:



OPERATION INFO 17 - Peck Drill

CYCLE TIME:

0 HOURS, 0 MINUTES, 39 SECONDS

COMMENT:

PROGRAM NUMBER: 33012

SPINDLE SPEED: 6621 RPM

FEEDRATE: 19.0703 inch/min

CLEARANCE PLANE: 0.25 RETRACT PLANE: 0.125 FEED PLANE: 0.125 DEPTH: -0.45 STOCK TO LEAVE: 0.0 COMP TO TIP: YES

WORK OFFSET: 0


TOOL INFO 3/16 DRILL

TYPE: Drill NUMBER: 4 0.1875 DIAMETER: **CORNER RADIUS:** 0.0 LENGTH OFFSET: 4 DIAMETER OFFSET: 4 MATERIAL: HSS 2

NUMBER OF FLUTES:

FPT: 0.0014 SFM: 69.9935

MFG CODE: ASSEMBLY:



OPERATION INFO 18 - Drill/Counterbore

CYCLE TIME:

0 HOURS, 0 MINUTES, 50 SECONDS

COMMENT:

PROGRAM NUMBER: 33012

SPINDLE SPEED: 855 RPM

FEEDRATE: 4.2442 inch/min


CLEARANCE PLANE: 0.25
RETRACT PLANE: 0.125
FEED PLANE: 0.125
DEPTH: -0.0625
STOCK TO LEAVE: 0.0
COMP TO TIP: YES
WORK OFFSET: 0

TOOL INFO 5/16 DRILL

TYPE: Drill NUMBER: 5 DIAMETER: 0.3125 **CORNER RADIUS:** 0.0 LENGTH OFFSET: 5 DIAMETER OFFSET: 5 MATERIAL: HSS NUMBER OF FLUTES: 2

FPT: 0.0025 SFM: 69.9444

MFG CODE: ASSEMBLY:



OPERATION INFO 19 - Tap

CYCLE TIME:

0 HOURS, 0 MINUTES, 33 SECONDS

COMMENT:

PROGRAM NUMBER: 33012

SPINDLE SPEED: 178 RPM

FEEDRATE: 11.125 inch/min

CLEARANCE PLANE: 0.25

RETRACT PLANE: 0.125

FEED PLANE: 0.125

DEPTH: 0.0

STOCK TO LEAVE: 0.0

COMP TO TIP: YES

WORK OFFSET: 0

TOOL INFO 3/8-16 TAPRH


TYPE: Right-hand tap

NUMBER: 6
DIAMETER: 0.375
CORNER RADIUS: 0.0
LENGTH OFFSET: 6
DIAMETER OFFSET: 6
MATERIAL: Carbide

NUMBER OF FLUTES:

FPT: 0.0625 SFM: 17.4738

MFG CODE: ASSEMBLY:



OPERATION INFO 20 - Contour (2D)

CYCLE TIME:

0 HOURS, 0 MINUTES, 6 SECONDS

COMMENT:

PROGRAM NUMBER: 33012

SPINDLE SPEED: 4966 RPM FEEDRATE: 39.0 inch/min

CLEARANCE PLANE: 2.0

RETRACT PLANE: 0.125

FEED PLANE: 0.05

DEPTH: -0.02

STOCK TO LEAVE: 0.0

COMP TO TIP: YES


WORK OFFSET: 0

TOOL INFO 1/8 SPOTDRILL

TYPE: Spot drill 7 NUMBER: 0.125 DIAMETER: **CORNER RADIUS:** 0.0 7 LENGTH OFFSET: DIAMETER OFFSET: 7 MATERIAL: HSS NUMBER OF FLUTES: 2

FPT: 0.0002 SFM: 69.9935

MFG CODE: ASSEMBLY:



TOOL LIST Sorted: NO


TOOL INFO 1/2 FLAT ENDMILL

TYPE: Flat endmill
NUMBER: 1
DIAMETER: 0.5
CORNER RADIUS: 0.0
LENGTH OFFSET: 1
DIAMETER OFFSET: 1
MATERIAL: HSS
NUMBER OF FLUTES: 4

FPT: 0.0131 SFM: 300.0

MFG CODE: ASSEMBLY:

HOLDER: Default Holder TIME: 00:03:24



USED BY OPERATION: #3 3 - 2D High Speed (2D Area Mill) **USED BY OPERATION:** #4 4 - 2D High Speed (2D Area Mill) USED BY OPERATION: #5 5 - 2D High Speed (2D Area Mill) **USED BY OPERATION:** #6 6 - 2D High Speed (2D Area Mill) **USED BY OPERATION:** #7 7 - Pocket (Standard) **USED BY OPERATION:** #8 8 - Pocket (Standard) **USED BY OPERATION:** #9 9 - Pocket (Standard) **USED BY OPERATION:** #10 10 - Pocket (Standard)

TOOL INFO 3/8 FLAT ENDMILL


TYPE: Flat endmill

NUMBER: 2
DIAMETER: 0.375
CORNER RADIUS: 0.0
LENGTH OFFSET: 2
DIAMETER OFFSET: 2
MATERIAL: HSS
NUMBER OF FLUTES: 4

FPT: 0.0011 SFM: 139.9869

MFG CODE: ASSEMBLY:

HOLDER: Default Holder TIME: 00:01:05



USED BY OPERATION: #11 11 - 2D High Speed (2D Dynamic Mill)

USED BY OPERATION: #12 12 - Contour (2D)

TOOL INFO 1/2 SPOTDRILL

TYPE: Spot drill
NUMBER: 3
DIAMETER: 0.5
CORNER RADIUS: 0.0
LENGTH OFFSET: 3
DIAMETER OFFSET: 3
MATERIAL: HSS
NUMBER OF FLUTES: 2

FPT: 0.001 SFM: 69.8953

MFG CODE: ASSEMBLY:

HOLDER: Default Holder TIME: 00:00:56

USED BY OPERATION: # 13 13 - Contour (2D chamfer)
USED BY OPERATION: # 14 14 - Contour (2D chamfer)
USED BY OPERATION: # 15 15 - Drill/Counterbore
USED BY OPERATION: # 16 16 - Drill/Counterbore

TOOL INFO 3/16 DRILL


TYPE: Drill NUMBER: 4 DIAMETER: 0.1875 **CORNER RADIUS:** 0.0 LENGTH OFFSET: 4 DIAMETER OFFSET: 4 MATERIAL: HSS NUMBER OF FLUTES: 2


FPT: 0.0014 SFM: 69.9935

MFG CODE: ASSEMBLY:

HOLDER: Default Holder TIME: 00:00:39

USED BY OPERATION: #17 17 - Peck Drill





TOOL INFO 5/16 DRILL

TYPE: Drill

NUMBER: 5

DIAMETER: 0.3125

CORNER RADIUS: 0.0

LENGTH OFFSET: 5

DIAMETER OFFSET: 5

MATERIAL: HSS

NUMBER OF FLUTES: 2

FPT: 0.0025 SFM: 69.9444

MFG CODE: ASSEMBLY:

HOLDER: Default Holder TIME: 00:00:50

USED BY OPERATION: #18 18 - Drill/Counterbore

TOOL INFO 3/8-16 TAPRH

TYPE: Right-hand tap


NUMBER: 6
DIAMETER: 0.375
CORNER RADIUS: 0.0
LENGTH OFFSET: 6
DIAMETER OFFSET: 6
MATERIAL: Carbide
NUMBER OF FLUTES: 1


FPT: 0.0625 SFM: 17.4738

MFG CODE: ASSEMBLY:

HOLDER: Default Holder
TIME: 00:00:33

USED BY OPERATION: #19 19 - Tap





TOOL INFO 1/8 SPOTDRILL


TYPE: Spot drill
NUMBER: 7
DIAMETER: 0.125
CORNER RADIUS: 0.0
LENGTH OFFSET: 7
DIAMETER OFFSET: 7
MATERIAL: HSS
NUMBER OF FLUTES: 2

FPT: 0.0002 SFM: 69.9935

MFG CODE: ASSEMBLY:

HOLDER: Default Holder TIME: 00:00:06

USED BY OPERATION: #20 20 - Contour (2D)



WORK OFFSETS

OFFSET INFO

NUMBER: 0 PLANI	Е: Тор		ORIGIN: 0.0, 0.0, 0.0
USED BY OPERATION:	#3	3 - 2D High Speed (2D Area Mill)	
USED BY OPERATION:	#4	4 - 2D High Speed (2D Area Mill)	
USED BY OPERATION:	#5	5 - 2D High Speed (2D Area Mill)	
USED BY OPERATION:	#6	6 - 2D High Speed (2D Area Mill)	
USED BY OPERATION:	#7	7 - Pocket (Standard)	
USED BY OPERATION:	#8	8 - Pocket (Standard)	
USED BY OPERATION:	#9	9 - Pocket (Standard)	
USED BY OPERATION:	# 10	10 - Pocket (Standard)	
USED BY OPERATION:	# 11	11 - 2D High Speed (2D Dynamic Mill)	
USED BY OPERATION:	# 12	12 - Contour (2D)	
USED BY OPERATION:	# 13	13 - Contour (2D chamfer)	
USED BY OPERATION:	# 14	14 - Contour (2D chamfer)	
USED BY OPERATION:	# 15	15 - Drill/Counterbore	
USED BY OPERATION:	# 16	16 - Drill/Counterbore	
USED BY OPERATION:	# 17	17 - Peck Drill	
USED BY OPERATION:	# 18	18 - Drill/Counterbore	
USED BY OPERATION:	# 19	19 - Тар	
USED BY OPERATION:	# 20	20 - Contour (2D)	