

GENERIC HAAS 3 - AXIS VMC

GENERAL INFORMATION


PROJECT NAME: **CUSTOMER NAME:** PROGRAMMER:

DRAWING: **REVISION:**


DATE: Friday, February 3, 2023

TIME: 8:38 PM

D:\SCHOOL\CNC\LESSON5_SECOND\V2\WSHAKESPEAR_MILL LESSON 5B.EMCAM



COMMENTS



STOCK: YES SHAPE: Box

SIZE: 3.0, 3.0, 0.25

RADIUS: NA

LENGTH:

AXIS: NA

FILE:

IDN: NA

C:\USERS\WES\DOCUMENTS\MY MASTERCAM

CYCLE TIME: 0 HOURS, 3 MINUTES, 18 SECONDS

OPERATION LIST

OPERATION INFO 1 - Contour (2D)

CYCLE TIME:

0 HOURS, 0 MINUTES, 11 SECONDS

COMMENT:

PROGRAM NUMBER: 0

SPINDLE SPEED: 5000 RPM FEEDRATE: 40.0 inch/min

CLEARANCE PLANE: 2.0

RETRACT PLANE: 0.02

FEED PLANE: 0.02

DEPTH: -0.007

STOCK TO LEAVE: 0.0

COMP TO TIP: YES

WORK OFFSET:

TOOL INFO

1/8 SPOTDRILL


TYPE: Spot drill
NUMBER: 1
DIAMETER: 0.125
CORNER RADIUS: 0.0
LENGTH OFFSET: 1
DIAMETER OFFSET: 1
MATERIAL: HSS

NUMBER OF FLUTES: 2

FPT: 0.0002 SFM: 69.9935

MFG CODE: ASSEMBLY:

HOLDER: Default Holder TIME: 00:00:11



WESTON

OPERATION INFO 2 - Drill/Counterbore

CYCLE TIME: 0 HOURS, 0 MINUTES, 1 SECONDS


COMMENT:

PROGRAM NUMBER: 0

SPINDLE SPEED: 5000 RPM FEEDRATE: 40.0 inch/min

CLEARANCE PLANE: 0.25
RETRACT PLANE: 0.15
FEED PLANE: 0.15
DEPTH: -0.01
STOCK TO LEAVE: 0.0
COMP TO TIP: NO

WORK OFFSET:




TOOL INFO 1/2 SPOTDRILL

TYPE: Spot drill
NUMBER: 2
DIAMETER: 0.5
CORNER RADIUS: 0.0
LENGTH OFFSET: 2
DIAMETER OFFSET: 2
MATERIAL: HSS

NUMBER OF FLUTES: 2

FPT: 0.001 SFM: 69.8953

MFG CODE: ASSEMBLY:



OPERATION INFO 3 - Peck Drill

CYCLE TIME:

0 HOURS, 0 MINUTES, 5 SECONDS

COMMENT:


PROGRAM NUMBER:

SPINDLE SPEED: 5000 RPM FEEDRATE: 20.0 inch/min

0

CLEARANCE PLANE: 0.25
RETRACT PLANE: 0.15
FEED PLANE: 0.15
DEPTH: -0.155
STOCK TO LEAVE: 0.0
COMP TO TIP: NO

WORK OFFSET:




TOOL INFO 1/4 DRILL

TYPE: Drill
NUMBER: 3
DIAMETER: 0.25
CORNER RADIUS: 0.0
LENGTH OFFSET: 3
DIAMETER OFFSET: 3
MATERIAL: HSS

NUMBER OF FLUTES: 2

FPT: 0.002 SFM: 69.9607

MFG CODE: ASSEMBLY:



CYCLE TIME:

0 HOURS, 0 MINUTES, 57 SECONDS

4 - Contour (2D)

COMMENT:

PROGRAM NUMBER:

SPINDLE SPEED: 5000 RPM FEEDRATE: 40.0 inch/min

0

CLEARANCE PLANE: 2.0

RETRACT PLANE: 0.25


FEED PLANE: 0.2

DEPTH: 0.0

STOCK TO LEAVE: 0.0

COMP TO TIP: YES

WORK OFFSET:




TOOL INFO 1/2 FLAT ENDMILL

TYPE: Flat endmill
NUMBER: 4
DIAMETER: 0.5
CORNER RADIUS: 0.0
LENGTH OFFSET: 4
DIAMETER OFFSET: 4
MATERIAL: HSS

NUMBER OF FLUTES: 4

FPT: 0.0015 SFM: 139.9215

MFG CODE: ASSEMBLY:



5 - Contour (2D)

CYCLE TIME:

0 HOURS, 0 MINUTES, 29 SECONDS

COMMENT:

PROGRAM NUMBER:

SPINDLE SPEED: 5000 RPM FEEDRATE: 40.0 inch/min

0

CLEARANCE PLANE: 2.0

RETRACT PLANE: 0.25


FEED PLANE: 0.2

DEPTH: 0.0

STOCK TO LEAVE: 0.0

COMP TO TIP: YES

WORK OFFSET:



TOOL INFO


1/2 FLAT ENDMILL

TYPE: Flat endmill
NUMBER: 4
DIAMETER: 0.5
CORNER RADIUS: 0.0
LENGTH OFFSET: 4
DIAMETER OFFSET: 4

MATERIAL: HSS NUMBER OF FLUTES: 4

FPT: 0.0015 SFM: 139.9215

MFG CODE: ASSEMBLY:



OPERATION INFO 6 - Contour (2D chamfer)

CYCLE TIME: 0 HOURS, 0 MINUTES, 24 SECONDS

COMMENT:

PROGRAM NUMBER: 0

SPINDLE SPEED: 5000 RPM FEEDRATE: 40.0 inch/min

CLEARANCE PLANE: 2.0

RETRACT PLANE: 0.25


FEED PLANE: 0.2

DEPTH: 0.125

STOCK TO LEAVE: 0.0

COMP TO TIP: YES

WORK OFFSET:




TOOL INFO 1/2 SPOTDRILL

TYPE: Spot drill
NUMBER: 2
DIAMETER: 0.5
CORNER RADIUS: 0.0
LENGTH OFFSET: 2
DIAMETER OFFSET: 2
MATERIAL: HSS

NUMBER OF FLUTES: 2

FPT: 0.001 SFM: 69.8953

MFG CODE: ASSEMBLY:



OPERATION INFO 7 - Contour (2D chamfer)

CYCLE TIME: 0 HOURS, 0 MINUTES, 11 SECONDS


COMMENT:

PROGRAM NUMBER: 0

SPINDLE SPEED: 4966 RPM FEEDRATE: 39.728 inch/min

CLEARANCE PLANE: 2.0
RETRACT PLANE: 0.25
FEED PLANE: 0.2
DEPTH: 0.125
STOCK TO LEAVE: 0.0
COMP TO TIP: YES

WORK OFFSET:




TOOL INFO 1/2 SPOTDRILL

TYPE: Spot drill
NUMBER: 2
DIAMETER: 0.5
CORNER RADIUS: 0.0
LENGTH OFFSET: 2
DIAMETER OFFSET: 2
MATERIAL: HSS

NUMBER OF FLUTES: 2

FPT: 0.001 SFM: 69.8953

MFG CODE: ASSEMBLY:



8 - Contour (2D chamfer)

CYCLE TIME:

0 HOURS, 0 MINUTES, 26 SECONDS

COMMENT:

PROGRAM NUMBER:

SPINDLE SPEED: 5000 RPM FEEDRATE: 40.0 inch/min

0

CLEARANCE PLANE: 2.0

RETRACT PLANE: 0.25


FEED PLANE: 0.2

DEPTH: 0.0

STOCK TO LEAVE: 0.0

COMP TO TIP: YES

WORK OFFSET:




TOOL INFO 1/2 SPOTDRILL

TYPE: Spot drill
NUMBER: 2
DIAMETER: 0.5
CORNER RADIUS: 0.0
LENGTH OFFSET: 2
DIAMETER OFFSET: 2
MATERIAL: HSS

NUMBER OF FLUTES: 2

FPT: 0.001 SFM: 69.8953

MFG CODE: ASSEMBLY:



9 - Contour (2D)

CYCLE TIME:

0 HOURS, 0 MINUTES, 30 SECONDS

COMMENT:

PROGRAM NUMBER:

SPINDLE SPEED: 5000 RPM FEEDRATE: 40.0 inch/min

0

CLEARANCE PLANE: 2.0

RETRACT PLANE: 0.25


FEED PLANE: 0.2

DEPTH: -0.125

STOCK TO LEAVE: 0.0

COMP TO TIP: YES

WORK OFFSET:




TOOL INFO 1/2 FLAT ENDMILL

TYPE: Flat endmill
NUMBER: 4
DIAMETER: 0.5
CORNER RADIUS: 0.0
LENGTH OFFSET: 4
DIAMETER OFFSET: 4
MATERIAL: HSS

NUMBER OF FLUTES: 4

FPT: 0.0015 SFM: 139.9215

MFG CODE: ASSEMBLY:



TOOL LIST Sorted: NO


TOOL INFO 1/8 SPOTDRILL

TYPE: Spot drill NUMBER: 1 DIAMETER: 0.125 CORNER RADIUS: 0.0 LENGTH OFFSET: 1 DIAMETER OFFSET: 1 MATERIAL: HSS NUMBER OF FLUTES: 2

FPT: 0.0002 SFM: 69.9935

MFG CODE: ASSEMBLY:

HOLDER: Default Holder TIME: 00:00:11



USED BY OPERATION: #1 1 - Contour (2D)


TOOL INFO 1/2 SPOTDRILL

TYPE: Spot drill NUMBER: 2 DIAMETER: 0.5 **CORNER RADIUS:** 0.0 LENGTH OFFSET: 2 DIAMETER OFFSET: 2 HSS MATERIAL: NUMBER OF FLUTES: 2

FPT: 0.001 SFM: 69.8953

MFG CODE: ASSEMBLY:

HOLDER: Default Holder TIME: 00:01:03



USED BY OPERATION: #2 2 - Drill/Counterbore

USED BY OPERATION: #6 6 - Contour (2D chamfer)

USED BY OPERATION: #7 7 - Contour (2D chamfer)

USED BY OPERATION: #8 8 - Contour (2D chamfer)


TOOL INFO 1/4 DRILL

TYPE: Drill
NUMBER: 3
DIAMETER: 0.25
CORNER RADIUS: 0.0
LENGTH OFFSET: 3
DIAMETER OFFSET: 3
MATERIAL: HSS
NUMBER OF FLUTES: 2

FPT: 0.002 SFM: 69.9607

MFG CODE: ASSEMBLY:

HOLDER: Default Holder TIME: 00:00:05



USED BY OPERATION: #3 3 - Peck Drill

TOOL INFO 1/2 FLAT ENDMILL

TYPE: Flat endmill

NUMBER: 4
DIAMETER: 0.5
CORNER RADIUS: 0.0
LENGTH OFFSET: 4
DIAMETER OFFSET: 4
MATERIAL: HSS
NUMBER OF FLUTES: 4

FPT: 0.0015 SFM: 139.9215

MFG CODE: ASSEMBLY:

HOLDER: Default Holder TIME: 00:01:57

-2.000 1.000 4.000 3.000

USED BY OPERATION: #4 4 - Contour (2D)
USED BY OPERATION: #5 5 - Contour (2D)
USED BY OPERATION: #9 9 - Contour (2D)

WORK OFFSETS

OFFSET INFO

NUMBER: PLANE	Е: Тор	ORIGIN: 0.0, 0.0, 0.0
USED BY OPERATION:	# 1	1 - Contour (2D)
USED BY OPERATION:	#2	2 - Drill/Counterbore
USED BY OPERATION:	#3	3 - Peck Drill
USED BY OPERATION:	#4	4 - Contour (2D)
USED BY OPERATION:	# 5	5 - Contour (2D)
USED BY OPERATION:	#6	6 - Contour (2D chamfer)
USED BY OPERATION:	#7	7 - Contour (2D chamfer)
USED BY OPERATION:	#8	8 - Contour (2D chamfer)
USED BY OPERATION:	#9	9 - Contour (2D)