

Setup Sheet Report

GENERIC HAAS 3 - AXIS VMC

GENERAL INFORMATION


PROJECT NAME: CUSTOMER NAME: PROGRAMMER:

DRAWING: REVISION:

DATE: Wednesday, February 22, 2023

TIME: 10:01 AM


C:\USERS\WESTONSHAKESPEAR\DOWNLOADS\WSHAKESPEAR_MILL 7B.EMCAM



	0.8807	in	
7	Inch		

CO	RЛ	NЛ	uп	re
υU	IVI	IVI	N I	

	·	



STOCK: YES SHAPE: Box

SIZE: 7.375, 3.625, 0.875

RADIUS: NA

LENGTH:

AXIS: NA

FILE:

IDN: NA

C:\USERS\WESTONSHAKESPEAR\DOCUMENTS\MY

CYCLE TIME: 0 HOURS, 17 MINUTES, 35 SECONDS

OPERATION LIST

OPERATION INFO 1 - Facing

CYCLE TIME: 0 HOURS, 1 MINUTES, 10 SECONDS

COMMENT:

PROGRAM NUMBER: 0

SPINDLE SPEED: 5000 RPM FEEDRATE: 49.0 inch/min

CLEARANCE PLANE: 2.0

RETRACT PLANE: 0.125


FEED PLANE: 0.025

DEPTH: 0.0

STOCK TO LEAVE: 0.0

COMP TO TIP: YES

WORK OFFSET: 0



TOOL INFO 1/2 FLAT ENDMILL


TYPE: Flat endmill

NUMBER: 1
DIAMETER: 0.5
CORNER RADIUS: 0.0
LENGTH OFFSET: 1
DIAMETER OFFSET: 1
MATERIAL: HSS

NUMBER OF FLUTES: 4

FPT: 0.0015 SFM: 139.9215

MFG CODE: ASSEMBLY:



OPERATION INFO 2 - 2D High Speed (2D Dynamic Mill)

CYCLE TIME: 0 HOURS, 3 MINUTES, 43 SECONDS

COMMENT:

PROGRAM NUMBER: 0

SPINDLE SPEED: 4966 RPM FEEDRATE: 49.0 inch/min

CLEARANCE PLANE: 0.0

RETRACT PLANE: 0.125


FEED PLANE: 0.1

DEPTH: 0.0

STOCK TO LEAVE: 0.0

COMP TO TIP: YES

WORK OFFSET: 0




TOOL INFO 1/2 FLAT ENDMILL

TYPE: Flat endmill

NUMBER: 1
DIAMETER: 0.5
CORNER RADIUS: 0.0
LENGTH OFFSET: 1
DIAMETER OFFSET: 1
MATERIAL: HSS
NUMBER OF FLUTES: 4

FPT: 0.0015 SFM: 139.9215

MFG CODE: ASSEMBLY:



OPERATION INFO 3 - 2D High Speed (2D Dynamic Rest Mill)

CYCLE TIME: 0 HOURS, 1 MINUTES, 2 SECONDS

COMMENT:

PROGRAM NUMBER: 0

SPINDLE SPEED: 4966 RPM FEEDRATE: 49.0 inch/min

CLEARANCE PLANE: 0.0

RETRACT PLANE: 0.125


FEED PLANE: 0.1

DEPTH: 0.0

STOCK TO LEAVE: 0.0

COMP TO TIP: YES

WORK OFFSET: 0




TOOL INFO 1/2 FLAT ENDMILL

TYPE: Flat endmill

NUMBER: 1
DIAMETER: 0.5
CORNER RADIUS: 0.0
LENGTH OFFSET: 1
DIAMETER OFFSET: 1
MATERIAL: HSS
NUMBER OF FLUTES: 4

FPT: 0.0015 SFM: 139.9215

MFG CODE: ASSEMBLY:



OPERATION INFO 4 - 2D High Speed (2D Dynamic Rest Mill)


CYCLE TIME: 0 HOURS, 5 MINUTES, 51 SECONDS

COMMENT:

PROGRAM NUMBER: 0

SPINDLE SPEED: 6621 RPM FEEDRATE: 49.0 inch/min

CLEARANCE PLANE: 0.0
RETRACT PLANE: 0.125
FEED PLANE: 0.1
DEPTH: 0.0
STOCK TO LEAVE: 0.0
COMP TO TIP: YES
WORK OFFSET: 0




TOOL INFO 3/8 FLAT ENDMILL

TYPE: Flat endmill

NUMBER: 2
DIAMETER: 0.375
CORNER RADIUS: 0.0
LENGTH OFFSET: 2
DIAMETER OFFSET: 2
MATERIAL: HSS
NUMBER OF FLUTES: 4

FPT: 0.0011 SFM: 139.9869

MFG CODE: ASSEMBLY:



OPERATION INFO 5 - 2D High Speed (2D Dynamic Rest Mill)


CYCLE TIME: 0 HOURS, 1 MINUTES, 24 SECONDS

COMMENT:

PROGRAM NUMBER: 0

SPINDLE SPEED: 4966 RPM FEEDRATE: 49.0 inch/min

CLEARANCE PLANE: 0.125
RETRACT PLANE: 0.0625
FEED PLANE: 0.05
DEPTH: 0.0
STOCK TO LEAVE: 0.0
COMP TO TIP: YES
WORK OFFSET: 0




TOOL INFO 3/8 FLAT ENDMILL

TYPE: Flat endmill

NUMBER: 2
DIAMETER: 0.375
CORNER RADIUS: 0.0
LENGTH OFFSET: 2
DIAMETER OFFSET: 2
MATERIAL: HSS
NUMBER OF FLUTES: 4

FPT: 0.0011 SFM: 139.9869

MFG CODE: ASSEMBLY:



OPERATION INFO 6 - Contour (2D chamfer)


CYCLE TIME: 0 HOURS, 0 MINUTES, 55 SECONDS

COMMENT:

PROGRAM NUMBER: 0

SPINDLE SPEED: 4966 RPM FEEDRATE: 20.0 inch/min

CLEARANCE PLANE: 0.125
RETRACT PLANE: 0.25
FEED PLANE: 0.2
DEPTH: 0.0
STOCK TO LEAVE: 0.0
COMP TO TIP: YES
WORK OFFSET: 0



TOOL INFO 1/2 SPOTDRILL

TYPE: Spot drill
NUMBER: 3
DIAMETER: 0.5
CORNER RADIUS: 0.0
LENGTH OFFSET: 3
DIAMETER OFFSET: 3
MATERIAL: HSS

NUMBER OF FLUTES: 2 FPT: 0.001 SFM: 69.8953

MFG CODE:

ASSEMBLY:
HOLDER: Default Holder

TIME: 00:00:55

7.000 1.000 4.000 3.000

OPERATION INFO 7 - Contour (2D chamfer)


CYCLE TIME: 0 HOURS, 0 MINUTES, 50 SECONDS

COMMENT:

PROGRAM NUMBER: 0

SPINDLE SPEED: 4966 RPM FEEDRATE: 20.0 inch/min

CLEARANCE PLANE: 0.125
RETRACT PLANE: 0.25
FEED PLANE: 0.2
DEPTH: 0.0
STOCK TO LEAVE: 0.0
COMP TO TIP: YES
WORK OFFSET: 0




TOOL INFO 1/2 SPOTDRILL

TYPE: Spot drill
NUMBER: 3
DIAMETER: 0.5
CORNER RADIUS: 0.0
LENGTH OFFSET: 3
DIAMETER OFFSET: 3
MATERIAL: HSS

NUMBER OF FLUTES: 2

FPT: 0.001 SFM: 69.8953

MFG CODE: ASSEMBLY:



OPERATION INFO

8 - Contour (2D chamfer)

CYCLE TIME:

0 HOURS, 0 MINUTES, 10 SECONDS

COMMENT:

PROGRAM NUMBER: 0

SPINDLE SPEED: 4966 RPM FEEDRATE: 20.0 inch/min

CLEARANCE PLANE: 0.125

RETRACT PLANE: 0.25


FEED PLANE: 0.2

DEPTH: 0.0

STOCK TO LEAVE: 0.0

COMP TO TIP: YES

WORK OFFSET: 0




TOOL INFO 1/2 SPOTDRILL

TYPE: Spot drill
NUMBER: 3
DIAMETER: 0.5
CORNER RADIUS: 0.0
LENGTH OFFSET: 3
DIAMETER OFFSET: 3
MATERIAL: HSS

NUMBER OF FLUTES: 2

FPT: 0.001 SFM: 69.8953

MFG CODE: ASSEMBLY:



OPERATION INFO

CYCLE TIME:

0 HOURS, 0 MINUTES, 5 SECONDS

9 - Contour (2D)

COMMENT:

PROGRAM NUMBER:

SPINDLE SPEED: 4966 RPM FEEDRATE: 49.0 inch/min

0

CLEARANCE PLANE: 0.125
RETRACT PLANE: 0.25
FEED PLANE: 0.2
DEPTH: -0.02
STOCK TO LEAVE: 0.0
COMP TO TIP: YES
WORK OFFSET: 0




TOOL INFO 1/8 SPOTDRILL

TYPE: Spot drill
NUMBER: 4
DIAMETER: 0.125
CORNER RADIUS: 0.0
LENGTH OFFSET: 4
DIAMETER OFFSET: 4
MATERIAL: HSS

NUMBER OF FLUTES: 2

FPT: 0.0002 SFM: 69.9935

MFG CODE: ASSEMBLY:



OPERATION INFO 10 - Drill/Counterbore

CYCLE TIME:


0 HOURS, 0 MINUTES, 10 SECONDS

COMMENT:

PROGRAM NUMBER: 0

SPINDLE SPEED: 9932 RPM FEEDRATE: 19.0712 inch/min

CLEARANCE PLANE: 0.125
RETRACT PLANE: 0.125
FEED PLANE: 0.125
DEPTH: -0.14
STOCK TO LEAVE: 0.0
COMP TO TIP: NO
WORK OFFSET: 0




TOOL INFO 1/2 SPOTDRILL

TYPE: Spot drill
NUMBER: 3
DIAMETER: 0.5
CORNER RADIUS: 0.0
LENGTH OFFSET: 3
DIAMETER OFFSET: 3
MATERIAL: HSS

NUMBER OF FLUTES: 2

FPT: 0.001 SFM: 69.8953

MFG CODE: ASSEMBLY:



OPERATION INFO 11 - Drill/Counterbore


CYCLE TIME: 0 HOURS, 0 MINUTES, 4 SECONDS

COMMENT:

PROGRAM NUMBER: 0

SPINDLE SPEED: 9932 RPM FEEDRATE: 19.0712 inch/min

CLEARANCE PLANE: 0.125
RETRACT PLANE: 0.125
FEED PLANE: 0.125
DEPTH: -0.208
STOCK TO LEAVE: 0.0
COMP TO TIP: NO
WORK OFFSET: 0




TOOL INFO 1/2 SPOTDRILL

TYPE: Spot drill
NUMBER: 3
DIAMETER: 0.5
CORNER RADIUS: 0.0
LENGTH OFFSET: 3
DIAMETER OFFSET: 3
MATERIAL: HSS

NUMBER OF FLUTES: 2

FPT: 0.001 SFM: 69.8953

MFG CODE: ASSEMBLY:



OPERATION INFO 12 - Peck Drill

CYCLE TIME:


0 HOURS, 0 MINUTES, 24 SECONDS

COMMENT:

PROGRAM NUMBER: 0

SPINDLE SPEED: 3216 RPM FEEDRATE: 10.0 inch/min

CLEARANCE PLANE: 0.125
RETRACT PLANE: 0.0625
FEED PLANE: 0.0625
DEPTH: -0.0965
STOCK TO LEAVE: 0.0
COMP TO TIP: NO
WORK OFFSET: 0




TOOL INFO LTR. W DRILL

TYPE: Drill
NUMBER: 5
DIAMETER: 0.386
CORNER RADIUS: 0.0
LENGTH OFFSET: 5
DIAMETER OFFSET: 5
MATERIAL: HSS

NUMBER OF FLUTES: 2

FPT: 0.003 SFM: 69.9246

MFG CODE: ASSEMBLY:



OPERATION INFO 13 - Peck Drill

CYCLE TIME:

0 HOURS, 1 MINUTES, 0 SECONDS


COMMENT:

PROGRAM NUMBER:

SPINDLE SPEED: 600 RPM FEEDRATE: 30.0 inch/min

0

CLEARANCE PLANE: 0.125
RETRACT PLANE: 0.125
FEED PLANE: 0.125
DEPTH: -0.201
STOCK TO LEAVE: 0.0
COMP TO TIP: NO
WORK OFFSET: 0




TOOL INFO NO. 7 DRILL

TYPE: Drill
NUMBER: 6
DIAMETER: 0.201
CORNER RADIUS: 0.0
LENGTH OFFSET: 6
DIAMETER OFFSET: 6
MATERIAL: HSS

NUMBER OF FLUTES: 2

FPT: 0.0048 SFM: 399.9479

MFG CODE: ASSEMBLY:



OPERATION INFO 14 - Tap

CYCLE TIME:


0 HOURS, 0 MINUTES, 39 SECONDS

COMMENT:

PROGRAM NUMBER: 0

SPINDLE SPEED: 600 RPM FEEDRATE: 30.0 inch/min

CLEARANCE PLANE: 0.125
RETRACT PLANE: 0.125
FEED PLANE: 0.125
DEPTH: 0.0
STOCK TO LEAVE: 0.0
COMP TO TIP: NO
WORK OFFSET: 0



TOOL INFO 1/4-20 TAPRH


TYPE: Right-hand tap

NUMBER: 7
DIAMETER: 0.25
CORNER RADIUS: 0.0
LENGTH OFFSET: 7
DIAMETER OFFSET: 7
MATERIAL: Carbide

NUMBER OF FLUTES: 1

FPT: 0.05 SFM: 17.4738

MFG CODE: ASSEMBLY:



TOOL LIST Sorted: NO

TOOL INFO 1/2 FLAT ENDMILL

TYPE: Flat endmill

NUMBER: 1

DIAMETER: 0.5

CORNER RADIUS: 0.0

LENGTH OFFSET: 1

DIAMETER OFFSET: 1


MATERIAL: HSS

NUMBER OF FLUTES: 4

FPT: 0.0015 SFM: 139.9215

MFG CODE: ASSEMBLY:

HOLDER: Default Holder TIME: 00:05:57



-2.000

USED BY OPERATION: #1 1 - Facing

USED BY OPERATION: #2 2 - 2D High Speed (2D Dynamic Mill)
USED BY OPERATION: #3 3 - 2D High Speed (2D Dynamic Rest Mill)

TOOL INFO 3/8 FLAT ENDMILL

TYPE: Flat endmill

NUMBER: 2
DIAMETER: 0.375
CORNER RADIUS: 0.0
LENGTH OFFSET: 2
DIAMETER OFFSET: 2
MATERIAL: HSS
NUMBER OF FLUTES: 4

FPT: 0.0011 SFM: 139.9869

MFG CODE: ASSEMBLY:

HOLDER: Default Holder TIME: 00:07:15

-2.000 -1.000 3.500 2.500

USED BY OPERATION: #4 4 - 2D High Speed (2D Dynamic Rest Mill)
USED BY OPERATION: #5 5 - 2D High Speed (2D Dynamic Rest Mill)

TOOL INFO 1/2 SPOTDRILL

TYPE: Spot drill
NUMBER: 3
DIAMETER: 0.5
CORNER RADIUS: 0.0
LENGTH OFFSET: 3
DIAMETER OFFSET: 3
MATERIAL: HSS
NUMBER OF FLUTES: 2

FPT: 0.001 SFM: 69.8953

MFG CODE: ASSEMBLY:

HOLDER: Default Holder TIME: 00:02:11


USED BY OPERATION: #6 6 - Contour (2D chamfer)
USED BY OPERATION: #7 7 - Contour (2D chamfer)
USED BY OPERATION: #8 8 - Contour (2D chamfer)
USED BY OPERATION: #10 10 - Drill/Counterbore
USED BY OPERATION: #11 11 - Drill/Counterbore


TOOL INFO 1/8 SPOTDRILL


TYPE: Spot drill
NUMBER: 4
DIAMETER: 0.125
CORNER RADIUS: 0.0
LENGTH OFFSET: 4
DIAMETER OFFSET: 4
MATERIAL: HSS
NUMBER OF FLUTES: 2

FPT: 0.0002 SFM: 69.9935

MFG CODE: ASSEMBLY:








TOOL INFO LTR. W DRILL

TYPE: Drill
NUMBER: 5
DIAMETER: 0.386
CORNER RADIUS: 0.0
LENGTH OFFSET: 5
DIAMETER OFFSET: 5
MATERIAL: HSS
NUMBER OF FLUTES: 2

FPT: 0.003 SFM: 69.9246

MFG CODE: ASSEMBLY:

HOLDER: Default Holder TIME: 00:00:24



USED BY OPERATION: #12 12 - Peck Drill

TOOL INFO NO. 7 DRILL

TYPE: Drill
NUMBER: 6
DIAMETER: 0.201
CORNER RADIUS: 0.0
LENGTH OFFSET: 6
DIAMETER OFFSET: 6
MATERIAL: HSS

NUMBER OF FLUTES: 2

FPT: 0.0048 SFM: 399.9479

MFG CODE: ASSEMBLY:

HOLDER: Default Holder TIME: 00:01:00

7.000 1.000 4.000 3.000

USED BY OPERATION: #13 13 - Peck Drill

TOOL INFO 1/4-20 TAPRH

TYPE: Right-hand tap

NUMBER: 7
DIAMETER: 0.25
CORNER RADIUS: 0.0
LENGTH OFFSET: 7
DIAMETER OFFSET: 7

MATERIAL: Carbide


NUMBER OF FLUTES:

FPT: 0.05 SFM: 17.4738

MFG CODE: ASSEMBLY:

HOLDER: Default Holder TIME: 00:00:39

USED BY OPERATION: #14 14 - Tap



WORK OFFSETS

OFFSET INFO

NUMBER: 0 PLANI	E: Top	ORIGIN: 0.0, 0.0, 0.0
USED BY OPERATION:	# 1	1 - Facing
USED BY OPERATION:	#2	2 - 2D High Speed (2D Dynamic Mill)
USED BY OPERATION:	#3	3 - 2D High Speed (2D Dynamic Rest Mill)
USED BY OPERATION:	#4	4 - 2D High Speed (2D Dynamic Rest Mill)
USED BY OPERATION:	#5	5 - 2D High Speed (2D Dynamic Rest Mill)
USED BY OPERATION:	#6	6 - Contour (2D chamfer)
USED BY OPERATION:	#7	7 - Contour (2D chamfer)
USED BY OPERATION:	#8	8 - Contour (2D chamfer)
USED BY OPERATION:	#9	9 - Contour (2D)
USED BY OPERATION:	# 10	10 - Drill/Counterbore
USED BY OPERATION:	# 11	11 - Drill/Counterbore
USED BY OPERATION:	# 12	12 - Peck Drill
USED BY OPERATION:	# 13	13 - Peck Drill
USED BY OPERATION:	# 14	14 - Тар